




VEGA
A B S O L U T E

GATEWAY

BS-1.2 / BS-2.2

USER MANUAL



| DOCUMENTATION REVISION | BS REVISION | SOFTWARE VERSION |
|------------------------|--------------|------------------|
| 35 | 6 and higher | 1.0 |

CONTENT

| | |
|---|----|
| INTRODUCTION..... | 4 |
| 1 DEVICE PURPOSE AND OPERATION PRINCIPAL..... | 5 |
| 2 SPECIFICATION..... | 6 |
| 3 OPERATION..... | 9 |
| Device Appearance | 9 |
| Control instruments – buttons and switches | 14 |
| SIM card installation at the BS-2.2..... | 15 |
| Indication | 17 |
| Antenna mounting recommendations..... | 18 |
| Mounting Recomendations..... | 19 |
| Maintenance recommendations | 22 |
| 4 CONFIGURING OF THE GATEWAY WITH WEB-INTERFACE | 24 |
| Interface launch – the operation begining | 24 |
| Gateway software updating | 30 |
| 5 CONFIGURING OF THE GATEWAY WITH TERMINAL PROGRAM..... | 31 |
| Gateway connecting to the computer – the operation begining | 31 |
| Operation with the configuration file | 35 |
| Configuration of a static IP-adress for the gateway..... | 39 |
| BS-2.2 Gateway setting up for LTE operation | 42 |
| Recommendations for gateway using in white IP net | 45 |
| 6 SAFE OPERATION RECOMMENDATIONS | 47 |

| | |
|--|----|
| General recommendations..... | 47 |
| ELECTRICAL SAFETY..... | 48 |
| SAFETY RULES IN CASE OF DAMAGE TO THE ENCLOSURE..... | 49 |
| RADIATION INFORMATION..... | 49 |
| 7 STORAGE AND TRANSPORTATION REQUIREMENTS | 50 |
| 8 CONTENT OF THE PACKAGE | 51 |
| 9 WARRANTY..... | 52 |

INTRODUCTION

This manual is designed for Vega BS-1.2 and Vega BS-2.2 gateways (hereinafter – the gateway) manufactured by Vega-Absolute OOO and provides information on powering and activation procedure, control commands and functions of the gateway.



Gateways can be supplied without software by request

This manual is targeted at specialists familiar with installation work fundamentals for electronic and electrical equipment.



**It is forbidden to use the device in case of any malfunctions
In the event of a malfunction, contact the manufacturer's technical support team**

In order to prevent possible personal injury and/or equipment damage, it is strongly recommended that you read the section "Recommendations for Safe Operation" before setting up and operating the equipment.



The gateway shall be installed and adjusted by qualified specialists to ensure proper operation of the device

Vega-Absolute OOO reserves the right to make changes to the manual related to the improvement of equipment and software, as well as to eliminate typos and inaccuracies, without prior notice.

1 DEVICE PURPOSE AND OPERATION PRINCIPAL

Vega BS gateway is designed to deploy LoRaWAN® network within 863-870 MHz frequency band.

The gateway operates with Linux operating system and is supplied with pre-installed Packet forwarder software.

The gateway is powered and communicates with the server via the Ethernet channel.

The device is configured through Ethernet with SSH protocol either via gateway web-interface or while USB connection with the computer. When gateway is connected via SSH or USB it may be configured with any terminal program (e. g. PuTTY).

Vega BS-2.2 gateway have a GSM/LTE module with the ability to install two Nano-SIM which provides an additional communication channel with a network server and a GPS/GLONASS module for determining the location of the gateway.

2 SPECIFICATION

| Model | BS-1.2 | BS-2.2 |
|---------------------------|------------------------|--|
| MAIN | | |
| GPS/GLONASS module | no | yes |
| GSM modem | no | yes |
| Server communication link | Ethernet 10/100 Base-T | Ethernet 10/100 Base-T, GSM LTE ¹ |
| Operating system | Linux | |
| USB-порт | yes | |
| Operating | -40...+70 °C | |
| LORAWAN® | | |
| Number of LoRa channels | 8 | |
| Frequency band | 863-870 MHz | |

¹ FDD-LTE (Cat.1): B1/B3/B5/B7/B8/B20

GSM/GPRS/EDGE: 900/1800MHz

| Receiver sensitivity | -141 dBm (при: LoRa, SF12, 125 kHz BW) | | | |
|-------------------------|--|---------------------|---------------------------|---|
| Power output | up to 500 mW | | | |
| Power output by default | 25 mW | | | |
| Antenna connector | N-Type female | | | |
| Data transfer rate | Data transfer rate (DataRate) | Configuration | Data transfer rate, bit/s | Signal/noise (SNR) of the minimal demodulation level (dB) |
| | DR0 | LFM: SF12 / 125 kHz | 250 | -20 |
| | DR1 | LFM: SF11 / 125 kHz | 440 | -17,5 |
| | DR2 | LFM: SF10 / 125 kHz | 980 | -15 |
| | DR3 | LFM: SF9 / 125 kHz | 1760 | -12,5 |
| | DR4 | LFM: SF8 / 125 kHz | 3125 | -10 |
| | DR5 | LFM: SF7 / 125 kHz | 5470 | -7,5 |
| | DR6 | LFM: SF7 / 250 kHz | 11000 | - |
| | DR7 | FSK: 50 kbit/s | 50000 | - |


| | |
|---|--------------------------------|
| Radio coverage in restrained urban conditions | up to 5 km |
| Radio coverage within line of sight | up to 15 km |
| POWER | |
| Power consumption | up to 10 W |
| Power supply | Passive PoE 4,5(+) 7,8(-) 15 W |
| CASE | |
| Housing dimensions | 192 x 183 x 75 mm |
| Ingress protection rating | IP67 |
| Mounting | mast supports |

3 OPERATION

DEVICE APPEARANCE


Gateway Vega BS is represented in strong case and compliant with a IP67 code. On the back side there is a mount for mounting on masts using metal clamps.

IP67




1 – N-connector for external antenna

2 – cable gland (would be one or two)



3 –mount for mounting on masts

4 – protective vent



5 – ground connection pin

The case is equipped with a hermetic gland of M12 size for round cable \varnothing 5-6 mm. A sealant is installed inside the gland, ensuring compliance with the declared Ingress Protection rating of the device case. Also, sealant is placed on the perimeter of case between two case parts. Removing the sealant can lead to moisture entering the gateway case. Waterproof protective vent serves to equalize the air pressure inside and outside the case.

The gateway terminal board has control and indication instruments, input, and output interfaces.

Location of elements on the board of the gateway BS-1.2

6 – 8P8C connector


7 – additional power connector

8 – slot for micro SD-card

9 – antenna connector

10 – group of indicators

11 – service switches



12 – mini USB port for connection to the computer

13 – USB host for connection external devices

14 – BS-Dashboard Web-interface launching

15 – gateway reset button

Location of elements on the board of the gateway BS-2.2

16 – SIM1

17 – 8P8C connector

18 – additional power connector


19 – slot for micro SD-card

20 – antenna connector

21 – SIM2

22 - group of indicators

23 – service switches




24 – mini USB port for connection to the computer

25 – USB host for connection external devices

26 – gateway reset button

27 – BS-Dashboard Web-interface launching

The gateway is connected to the network with an 8-core network cable (twisted pair) through 8P8C connector on the board. Cable shall be crimped in compliance with T568A and T568B standards. Contacts are numerated from 1 to 8 in order right-to-left.



Colors are shown for cable T568B:

| Contact number | Color | Designation |
|----------------|------------------|-------------|
| 1 | Orange-and-white | TD+ signal |
| 2 | Orange | TD- signal |
| 3 | Green-and-white | RD+ signal |
| 4 | Blue | Power |
| 5 | Blue-and-white | Power |
| 6 | Green | RD- signal |
| 7 | Brown-and-white | Ground |
| 8 | Brown | Ground |


There is an additional power connector on the board. It can be connectable only when power contacts 4, 5 and 7, 8 in the network cable are disabled. Permissible power voltage is 12-48 V. Minimum power is 10 W.

CONTROL INSTRUMENTS – BUTTONS AND SWITCHES

There are two buttons on the gateway board. BT1 launches BS-Dashboard Web-interface. Press RST button for the gateway instantaneous rebooting.




In addition, there are service switches on the board used to select the download option of the firmware image: from internal memory, from the SD card or via USB-host from the computer. The switches are only for service conditions. In operating mode switches shall be disable, see picture below.




SIM CARD INSTALLATION AT THE BS-2.2

Vega BS-2.2 gateway includes a GSM/LTE module, which is placed on the main board.



The SIM card must be installed at a temperature not lower than room temperature. If the device was in low temperatures, then before installing the SIM card, you must first keep the device at room temperature for several hours.

The gateway uses 2 nano-SIM cards. The SIM card slots are located on the top surface of the module.



INDICATION

There is a group of LED indicators on the terminal board; their signals showing in the table below. They indicate operation of different systems: power (on / off), visibility of GPS satellites, GSM modem (on / off), operation of the LoRa signals processing program (Packet forwarder on/off), Ethernet activity.

| LED | Color | Indication |
|------------------|--------|---|
| ETH_LINK | Green | <i>Flashes</i> – activity via Ethernet |
| GPS ² | Blue | <i>Doesn't light</i> – no data from GPS-receiver <i>Flashes</i> – there data exist, but are not valid for use by Packet forwarder <i>Lights</i> – location identified |
| LoRa | Yellow | <i>Lights</i> – Packet forwarder is started <i>Doesn't light</i> – Packet forwarder is stopped |
| GSM | Green | <i>Lights</i> – GSM-modem is enabled <i>Doesn't light</i> – GSM-modem is disabled |
| PWR | Red | <i>Lights</i> – operation system kernel is running <i>Doesn't light</i> – gateway is not powered |

² GPS LED indicates the GPS system functioning only while Packet forwarder processing (LoRa LED lights).

ANTENNA MOUNTING RECOMMENDATIONS

The Antenna usually has fasteners for installation on a mast support. To ensure maximum communication range, follow the installation guidelines for the antenna:

1. The antenna should be installed outdoors, preferably on the roof of a building that is 5-7 meters higher than the surrounding buildings. Installing the antenna indoors significantly reduces the sensitivity of the antenna.
2. It is advisable to remove the antenna installation site from the equipment of cellular operators, metal structures and other objects that create a "radio shadow" or a zone of reduced radio signal by 30-50 meters. After all tests have been completed, you can bring the antenna closer to the equipment of the mobile operator if the communication quality is satisfactory.
3. Barriers such as railings and advertising structures can also degrade the radio signal, so it is recommended to place the antenna at a height of at least 3 meters above the roof surface of the building.
4. The gateway must also be installed in close proximity to the antenna - up to the length of the antenna's coaxial wire. An additional increase in the length of the cable between the antenna and the base station will lead to a loss of antenna sensitivity.



For example, 25 meters of RG-58 cable attenuate the signal by 14 dBm, i. e. if transmission power is 14 dBm (25mW), the power on the antenna will be 1mW

5. The antenna directional pattern shall be considered. In the horizontal plane, the antenna has a circular direction, but no vertical direction. Therefore, the quality of communication directly under the antenna will be worse than at some distance from the antenna.

MOUNTING RECOMENDATIONS


The necessary stage for the network deploying including a big quantity of end devices is a radio planning work with nature experiments.

For mounting you will need:


- ◎ cross-shaped screwdriver for gateway assembling;
- ◎ mounting belts and tool for them;
- ◎ wire cutters;
- ◎ a set of tools for cable crimping (stripper, crimper, twisted pair tester, cap, connector);
- ◎ antenna mounting wrenches;
- ◎ laptop.

Step by step mounting guide:

1. Setting the gateway is usually carried out in the office (see Network Deployment Manual).
2. Determination of suitable places for mounting at the object with a network tester – radio planning work.
3. Antenna placement and mounting. It's important to place the gateway antenna properly for high-quality signal reception.
4. Connection PoE-injector cable to the gateway. To do this, you need to pass it through the cable gland of the case, and then crimp it with an Ethernet connector.



5. Gateway placement on the pole with mounting belts.
6. Power applying on the PoE.
7. By the laptop you can make sure that the device successfully sends the data.
8. Installing and fixing the cover of the gateway with screws, installing the silicone plugs that come with the kit.





WARNING. The tightening force of the screws must not exceed 0.8 Nm.
Exceeding the tightening force may cause the housing to break and lose its tightness

MAINTENANCE RECOMMENDATIONS

To prevent equipment failures during operation, it is recommended to carry out periodic maintenance of the gateway. The maintenance period is set depending on the operating conditions and can be from 6 to 24 months.

List of possible works during maintenance:

1. Checking the operation status of the gateway.
2. Software updating.
3. Cleaning external elements from dust.
4. Maintenance of mounting, external mounting wires, contact connections.
5. Checking the operation status of the PoE-injector.

The recommended order for each type of work is given in the table below.

| Maintenance | Auxiliary materials and tools | Maintenance procedure |
|--|--|---|
| Checking the operation status of the gateway | ◎ cross-shaped screwdriver for gateway assembling. | <ol style="list-style-type: none"> 1. Disassemble the gateway case, remove the cover 2. Make sure that all LEDs from the group of BS status indicators are light according to the table 3. Install the cover in place, assemble the BS |
| Software updating | ◎ laptop. | <ol style="list-style-type: none"> 1. Connect to the gateway via the Web-interface 2. Check for an update (exclamation mark next to the "About Device" section) 3. Update software |
| Cleaning external elements from dust | ◎ microfiber cloth. | <ol style="list-style-type: none"> 1. De-energize the BS 2. Wipe the outer parts of the BS case with a damp cloth |

| | | |
|---|---|--|
| | | <ol style="list-style-type: none"> 3. Wipe the PoE-injector with a damp cloth 4. Wipe the antenna |
| Maintenance of mounting | <ul style="list-style-type: none"> ◎ mounting belts and tool for them; ◎ antenna mounting wrenches. | <ol style="list-style-type: none"> 1. Carefully check the security of the gateway 2. If necessary, tighten the screws or replace the ties 3. Check the reliability of the antenna mounting |
| Maintenance of external mounting wires, contact connections | <ul style="list-style-type: none"> ◎ cross-shaped screwdriver for gateway assembling; ◎ insulating tape; ◎ cable glands, wires and cables for replacement; ◎ a set of tools for cable crimping. | <ol style="list-style-type: none"> 1. Inspect the external mounting wires of the BS, antenna and PoE-injector for abrasions and damage 2. If necessary, replace the wires or repair the insulation 3. Make sure that the contact connections are tight 4. Make sure that the cable glands are in good condition, and the seal is intact 5. If necessary, replace the cable glands |
| Checking the operation status of the PoE-injector | <ul style="list-style-type: none"> ◎ multimeter. | <ol style="list-style-type: none"> 1. Make sure the PoE-injector LED is green 2. Disconnect the Ethernet cable 3. Measure the voltage at the power outputs of the PoE-injector with a multimeter 4. Make sure the voltage is $48V \pm 1V$ |

4 CONFIGURING OF THE GATEWAY WITH WEB-INTERFACE

INTERFACE LAUNCH – THE OPERATION BEGINING

Web-interface software consist of two parts:

1. Server's API "BS-Dashboard" which (in depending on received data) transmits current settings, device information and saved new settings at the device memory. API «BS-Dashboard» is available on the port 3001 by default.
2. Client's Web-application operating with server's API "BS-Dashboard" – is developed for visual displaying data, for validation of changes and for sending the settings to save at the device. Client's Web-application is available on the port 80.

"BS-Dashboard" launched by the pressing the button BT1 on the gateway board. It may be changed in the settings. After holding the button in a pressed state during more than 6 seconds the launch begins, which may be continuing about 1 or 2 minutes in depending on the device loading.

For entering to a client's web-application IP-address of the gateway is needed. You can find out it with terminal program (for example, with a free PuTTY program). Part 5 describes in detail how to connect to a gateway with a terminal program. You should enter the command `ifconfig` in terminal window.


```
root@imx6ull-vega-00374-03:~#  
root@imx6ull-vega-00374-03:~# ifconfig  
eth0      Link encap:Ethernet HWaddr ae:a6:4a:64:87:b5  
          inet addr:10.10.70.193 Bcast:10.10.70.255 Mask:255.255.255.0  
          inet6 addr: fe80::aca6:4aff:fe64:87b5/64 Scope:Link  
             UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1  
             RX packets:294017 errors:0 dropped:0 overruns:0 frame:0  
             TX packets:159014 errors:0 dropped:0 overruns:0 carrier:0  
             collisions:0 txqueuelen:1000  
             RX bytes:26463535 (25.2 MiB) TX bytes:18228264 (17.3 MiB)  
  
lo       Link encap:Local Loopback  
          inet addr:127.0.0.1 Mask:255.0.0.0  
          inet6 addr: ::1/128 Scope:Host  
             UP LOOPBACK RUNNING MTU:65536 Metric:1  
             RX packets:9482 errors:0 dropped:0 overruns:0 frame:0  
             TX packets:9482 errors:0 dropped:0 overruns:0 carrier:0  
             collisions:0 txqueuelen:1000  
             RX bytes:474100 (462.9 KiB) TX bytes:474100 (462.9 KiB)  
  
root@imx6ull-vega-00374-03:~#
```

The next step is to open a browser and enter IP-address in the address bar. If the "BS-Dashboard" server is launched successfully then the authorization page for login into the client's Web-application will appear.




If there is no connection to Web-interface and authorization page is not appearing, then you need to add port number 80 to IP address of the gateway in the address bar.

It may look like this, for example: <http://192.168.1.228:80>




After entering login and password of the gateway (root and tempwd by default) gateway's Web-interface page appears.

At the top of the page is the name of the menu section in which you are currently.



The screenshot shows the Vega BS Gateway Web-interface. The left sidebar has a blue background with white text and icons. It includes links for LoRaWAN Server Settings (highlighted with a red box), Frequency Plan Settings, GPS Settings, Other LoRa Settings, LoRa Log, LTE Settings, Network Settings, About Device, Settings, Actions, and Expert Mode. The main content area has a white background. At the top right are language selection buttons (RU EN) and a Log out button. Below them is a section titled "LoRaWAN Server Settings" with three input fields: "Server address" (10.10.40.20), "LoRa server port up" (1700), and "LoRa server port down" (1700). Each field has a small info icon (i) to its right.

If the Web-interface is launched by pressing the button, then when the gateway is restarted, it will become unavailable again. For the Web-interface to always be available, you need to change the server startup settings. To do this, go to the "Settings" menu, then "Manager Settings" and in the "BS-Dashboard Server Startup Method" field change the value to "Always On". After that, be sure to click the "Save" button so that the settings go to the gateway.



Gateway
Gateway ID: AA555A000000000000

RU EN
Log out ↗

LoRaWAN Server Settings
Frequency Plan Settings
GPS Settings
Other LoRa Settings
LoRa Log
LTE Settings
Network Settings
About Device
Settings
Actions
Expert Mode:

Settings

Change WEB interface password:

Current password ⚠

New password ⚠

New password 2

Save password

Manager settings ▲

Update settings:

Update check interval (minutes)

Other manager settings:

"BS-Dashboard" server startup method: Always on ⓘ

Logger level: Info (recommended) ⓘ

Set configs Re-request configs

"BS-Dashboard" settings ▼

The main features of working with the Web-interface:

1. If you change something in any menu, and then proceed to the next, these changes are saved in the client, but not saved on the gateway, and the edit icon appears in the menu block, where the unsaved changes remained.

LoRaWAN Server Settings

Server address: 10.10.70.135

LoRa server port up: 8001


LoRa server port down: 8001

Set gateway configs Re-request gateway configs

2. To apply the settings changes at the gateway, you always need to click the "Save" button.
3. If you click the "Reset these settings" button, then all unsaved changes will be lost.
4. The buttons "Save" and "Reset settings" apply only to the group of parameters under which they are directly located.
5. The "Expert" mode allows you to see additional settings in the sections "Frequency plans", "LTE settings", "Network settings", "Settings" (only the "Manager settings" subsection) and "Actions".

GATEWAY SOFTWARE UPDATING

If the latest software updates are available, an exclamation mark icon will be displayed next to the "About Device" section. In this case, go to this section and click the "Update" button.



The screenshot shows the Vega BS Gateway software interface. The left sidebar contains navigation links: LoRaWAN Server Settings, Frequency Plan Settings, GPS Settings, Other LoRa Settings, LoRa Log, LTE Settings, Network Settings, About Device (highlighted with a red box), Settings, Actions, and Expert Mode. The main content area has a blue header bar labeled "About Device". Below it, the "Device info:" section lists the following details:

| | |
|---------------------|--------------------|
| Gateway ID | AA555A000000000000 |
| Device model | BS-2.2 |
| Board revision | 06 |
| Date of manufacture | 07.09.2022 |
| GNSS unit | Ublox EVA M8M |
| GSM unit | SIMCom A7672E |
| Is support LTE | Yes |

The "Packet forwarder:" section shows Version 4.0.1. The "Device operation system:" section shows Type Linux, Architecture x64, and Release 5.10.16.3-microsoft-standard-WSL2. The "Device GUI server:" section shows Version s-0.9.0/c-0.10.0 and Manager(updater) version 0.5.4. A green banner at the bottom indicates a new version is available: s-0.8.6/c-0.9.0 (2022-05-06T03:57:38Z) and a new manager version is available: 0.9.4 (2019-10-21T06:40:48Z). A pink box highlights the "Update" button in the green banner.

5 CONFIGURING OF THE GATEWAY WITH TERMINAL PROGRAM


GATEWAY CONNECTING TO THE COMPUTER – THE OPERATION BEGINING

Connection is possible, for example, with a free PuTTY program. There are two ways of connection to the gateway – with direct connection via USB or remote connection via SSH.


1. Connection via USB

In case of a USB connection, you need to connect the gateway to a personal computer with a mini-USB connector by a cable. Next, connect to a virtual COM port by installing the driver for MCP2200 or CP210x depends on installed USB-port on the board of the exact device. "Ports (COM and LPT)" menu appears at the device manager.

Search "USB Serial Port" in the "Ports" menu and see its number.




Open PuTTY, select Serial, enter number of the gateway virtual COM-port and speed (115200) in the corresponding fields.



Press "Open" button.

2. Connection via SSH

The direct connection to gateway is not required in case of SSH connection. Select SSH connection in the PuTTY dialog box, enter the device's IP-address and port 22. By default, the device obtains an IP-address via DHCP when connected via Ethernet.




Press "Open" button.

After connecting to the gateway by one of the methods, PuTTY terminal window appears where you should enter login and password. By default, login ***root*** and password ***temppwd***(symbols not displaying while entering the password) are used for connection to the

gateway. At the first connection, it is recommended to change the password for individual access.



By default, a user with root rights is denied ssh login, and therefore, ssh login must be performed under the admin user, the password remains the default.




```
imx6ull-vega-00374-03 login:
```

Now the configuration can be carrying out.

OPERATION WITH THE CONFIGURATION FILE

Packet forwarder starts automatically when the system starts. Before the gateway configuring, stop Packet forwarder by entering command:

```
systemctl stop lora_pkt_fwd
```




```
root@imx6ull-vega-00374-03:~# systemctl stop lora_pkt_fwd
root@imx6ull-vega-00374-03:~# nano /etc/LoRa/global_conf.json
root@imx6ull-vega-00374-03:~#
```

Configuration file **global_conf.json** is in the directory `cd /etc/LoRa/` – it may contain frequency band, the gateway ID, IP-address and server ports settings.

Enter the command, containing the required configuration file to change the settings.

After all changes completed enter the command:

```
systemctl start lora_pkt_fwd
```



```
root@imx6ull-vega-00374-03:~#
root@imx6ull-vega-00374-03:~#
root@imx6ull-vega-00374-03:~#
root@imx6ull-vega-00374-03:~#
root@imx6ull-vega-00374-03:~# systemctl start lora_pkt_fwd
root@imx6ull-vega-00374-03:~#
```

Packet forwarder will automatically start with new settings.



To connect the gateway to the server, you must use the UDP port specified in the server configuration file. On the gateway, the port configuration is in the `global_conf.json` file

In the `global_conf.json` file, the UDP port settings are in the `gateway_conf` section, there are `server_port_up` and `server_port_down` parameters.

10.10.96.217 - Tera Term VT

Файл Операции Настройка Управление Окно Помощь

GNU nano 2.2.6 File: LoRa/global.conf.json

```

        "bandwidth": 125000,
        "datarate": 50000
    }
},
"gateway_conf": {
    "gateway_ID": "98f07bFFFFE066db6",
    "server_address": "10.10.3.45",
    "serv_port_up": 1700,
    "serv_port_down": 1700,
    "keepalive_interval": 10,
    "autoquit_threshold": 10,
    "stat_interval": 30,
    "push_timeout_ms": 100,
    "forward_crc_valid": true,
    "forward_crc_error": false,
    "forward_crc_disabled": false,
    "gps_tty_path": null,
    "ref_latitude": 0,
    "ref_longitude": 0,
    "ref_altitude": 0,
    "fake_gps": false
},
^G Get Help ^O WriteOut ^R Read File ^Y Prev Page ^K Cut Text ^C Cur Pos
^X Exit ^J Justify ^H Where Is ^V Next Page ^U UnCut Text ^T To Spell

```

In order to communicate with the server correctly, you should make sure that these UDP port parameters correspond to those specified in the server configuration file (see details in the «IOT Vega Server Manual»).

To replace configuration file (for example, for change frequency plan) you need to make the following steps:

1. Go to Packet forwarder directory by the command:
`cd /etc/LoRa/`

2. If there is no file with the required frequency plan in the specified directory, then download it from the FTP storage using the command (following command is exactly for that file):

For BS-1.2

wget

ftp://lora_guest:vnm\\$4JHW@178.208.75.230:21/BS_x.2/rev.6/BS_1.2_rev.6/global_conf_EU868.json

For BS-2.2

wget

ftp://lora_guest:vnm\\$4JHW@178.208.75.230:21/BS_x.2/rev.6/BS_2.2_rev.6/global_conf_EU868.json

3. Make a copy of downloaded file (global_conf_EU868 in our example) with a new name global_conf.json by the command:

cp EU868_global_conf.json global_conf.json

4. Open file global_conf.json by the command:

nano LoRa/global_conf.json

and specify parameters, - “*gateway_ID*”, “*server_address*”, “*serv_port_up*”, “*serv_port_down*”, and then save and close the file.

Parameter *gateway_ID* is formed out of gateway MAC address and “FFFE” symbols.

For example:

To get gateway MAC address you need to enter a command **ifconfig**

```
root@am335x-evm:~# ifconfig
eth0      Link encap:Ethernet HWaddr 98:F0:7B:A7:55:58
          inet addr:10.10.70.174 Bcast:0.0.0.0 Mask:255.255.255.0
          UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
          RX packets:6774 errors:0 dropped:0 overruns:0 frame:0
          TX packets:2803 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:571437 (558.0 KiB) TX bytes:359977 (351.5 KiB)
          Interrupt:56


lo        Link encap:Local Loopback
          inet addr:127.0.0.1 Mask:255.0.0.0
          UP LOOPBACK RUNNING MTU:65536 Metric:1
          RX packets:428 errors:0 dropped:0 overruns:0 frame:0
          TX packets:428 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:0
          RX bytes:21400 (20.8 KiB) TX bytes:21400 (20.8 KiB)
```

In our example MAC address is: 98:F0:7B:A7:55:58.

Then you need to copy that MAC address, delete ":" symbols and put "FFFE" at the middle of line.

Example of ready *gateway_ID*: 98F07B~~FF~~EEA75558

In order to do this through a script, you need to run the **update_gwid.sh** command




```
COM156 - PuTTY
root@imx6ull-vega-00374-03:~# update_gwid.sh
Usage: /usr/bin/update_gwid.sh [filename]
      filename: Path to JSON file containing Gateway_ID for packet forwarder
root@imx6ull-vega-00374-03:~#
```

5. Restart gateway by the command: **reboot**

CONFIGURATION OF A STATIC IP-ADRESS FOR THE GATEWAY

Configuration of a static IP is carrying out with the terminal program in the following way:

1. After connecting to the gateway, enter login and password in the PuTTY terminal window.
2. Open file `nano cd /etc/systemd/network/80-wired.network/` and modify it:




The screenshot shows a PuTTY terminal window titled "COM156 - PuTTY". The command line at the top shows the path: [1/1] /etc/systemd/network/80-wired.network. The terminal displays the contents of the 80-wired.network file, which includes a [Match] section and a [Network] section. The [Network] section contains DHCP=yes, #DNS=8.8.8, #Address=10.10.96.101/24, and #Gateway=10.10.96.1. Below this is a [DHCP] section with RouteMetric=10 and ClientIdentifier=mac. At the bottom of the terminal window, there is a menu bar with options like Get Help, Write Out, Where Is, Cut Text, Justify, Cur Pos, Exit, Read File, Replace, Paste Text, To Spell, Go To Line, and a status message "[80-wired.network -- 13 lines]". The command "cd pp" is entered at the bottom of the terminal window.

3. That are strings exactly:

```
[Network]
DHCP=yes
#DNS=8.8.8.8
#Address=10.10.96.101/24
#Gateway=10.10.96.1
```

4. To work in static IP mode, comment the 2nd string.
 5. Uncomment 3-5th strings and also specify your address, netmask and gateway parameters - the result is in the screenshot below (but other address values):



The screenshot shows a PuTTY terminal window titled "COM156 - PuTTY". The current file being edited is "/etc/systemd/network/80-wired.network". The content of the file is as follows:

```
[Match]
Name=en* eth*
KernelCommandLine=!nfsroot
[Network]
#DHCP=yes
Address=192.168.1.1/24
Gateway=192.168.1.0
DNS=8.8.8.8
[DHCP]
RouteMetric=10
ClientIdentifier=mac
```

The line "#DHCP=yes" is preceded by a green highlight, indicating it has been uncommented. The bottom of the terminal shows standard PuTTY keyboard shortcuts.



In that example shown setting of the static IP-address 192.168.1.1 and gateway 192.168.1.0
 You need to change those values to others, which are necessary to your own case


6. Type reboot in command line for gateway restarting with new settings.

7. Going back is similar.

BS-2.2 GATEWAY SETTING UP FOR LTE OPERATION

Gateway BS-2.2 setting up for LTE operation using the terminal program is in the following order for each SIM separately:

Check, that in files `nano provider1-connect-chat` и `nano provider2-connect-chat` located `cd /etc/ppp/` there are strings highlighted in red:



The screenshot shows a PuTTY terminal window titled "COM156 - PuTTY". The window displays a configuration file for a PPP connection named "provider2-connect-chat". The file contains the following text:

```
GNU nano 4.4                               provider2-connect-chat
# Chat скрипт подключает modem к провайдеру
ABORT "BUSY"
ABORT "NO CARRIER"
ABORT "NO DIALTONE"
ABORT "ERROR"
ABORT "NO ANSWER"
TIMEOUT 30
"" AT
OK ATE0
OK ATH
OK ATI;+CSUB;+CSQ;+CPIN?;+COPS?;+CGREG?;&D2
# Insert the APN provided by your network operator
OK AT+CGDCONT=1,"IP","internet.megafon.ru",,0,0
OK ATD*100#
CONNECT
```


The APN value "internet.megafon.ru" is highlighted in red. At the bottom of the terminal window, there is a menu bar with options like Get Help, Write Out, Where Is, Cut Text, Justify, Cur Pos, Exit, Read File, Replace, Paste Text, To Spell, and Go To Line. A status bar at the bottom indicates "[Read 15 lines]".

where "`internet.megafon.ru`" is APN cellular operator. Change APN value according to APN cellular operator.



**In that example shown LTE setting for Megafon cellular operator
You need to change those values to others, which are necessary to your
own case**

The username and password are written in the pap-secrets file located along the path
cd /etc/ppp/



```
GNU nano 4.4                               pap-secrets
Secrets for authentication using PAP
# client      server    secret          IP addresses
beeline * 66666 *
megafon * 99999 *
```

[Read 4 lines]

^G Get Help ^O Write Out ^W Where Is ^K Cut Text ^J Justify ^C Cur Pos
^X Exit ^R Read File ^\ Replace ^U Paste Text ^T To Spell ^^ Go To Line

Where **beeline** is the login and **66666** is the password.



Password and Username fields could not be empty, if those parameters are not used by the cellular operator, then you may to enter 'internet' word at both fields for example



BS-2.2 gateways are switching between Ethernet and LTE automatically



If you use such two communication channels as Ethernet and LTE at the same time you should to remember that Ethernet has a priority for communication and LTE used as a backup option if gateway cannot communicate with the server via Ethernet


For recommendations for gateways using white IP, see below.

RECOMMENDATIONS FOR GATEWAY USING IN WHITE IP NET

In case the BS is used in network with white IP, it is recommended to change the standard port numbers of ssh and telnet to others. This should be considered while port forwarding. The steps sequence for changing BS dropbear and telnetd ports is described below.

To change ssh port:

1. Enter at the command line of the terminal program
`nano /lib/systemd/system/dropbear.socket`
2. Open file `nano /lib/systemd/system/dropbear.socket`



```
GNU nano 4.4          /lib/systemd/system/dropbear.socket
[Unit]
Conflicts=dropbear.service

[Socket]
ListenStream=27
Accept=yes

[Install]
WantedBy=sockets.target
Also=dropbearkey.service
```

3. Find string `ListenStream=27` and change standard port «27» to another, then save the file.
4. Enter at the command line of the terminal program `systemctl daemon-reload` and restart `systemctl restart dropbear.socket`

The gateway has OpenVPN client. Configuring VPN connection is covered in a separate document by software developer.

6 SAFE OPERATION RECOMMENDATIONS

GENERAL RECOMMENDATIONS

Before starting work with the Vega BS, you should learn this Operation Manual (hereinafter referred to as the Manual).

This device is designed for LoRaWAN® network deployment in the 863-870 MHz range. Using the device for purposes other than those specified in this manual is a violation of the operating rules. The producer is not liable for any damage resulting from improper use of the device.

The Vega BS device should be operated by a trained person.



The device isn't intended for use by children or in areas where children may be present



Prohibited:
**independent repair of the device, making changes to the device design,
installation of any software (except for the producer's software)**

Unprofessionally performed repair work or installed third party software can result in device failure, personal injury, and property damage.



**The producer does not assume liability for unpredictable effects resulting
from the use of third party software on the device**

ELECTRICAL SAFETY



Do not operate the device near an open flame or direct sunlight. Doing so may result in overheating and fire. The device should be used at air temperatures range from -40 °C (-40 F) to +70 °C (158 F)

If a fire is detected, immediately stop using the device and eliminate the fire. After that, the device should be sent to the producer for diagnostics (See the Warranty section for the producer's contacts).

Don't allow foreign objects to get into the device case during operation, as this may result in short circuits and fire. Don't operate the device with the case open or damaged.



Accidental damage to the power cable may result in electric shocks and faults that are not covered under the warranty terms

Prohibited to immerse the device case in water, it is not recommended to put it under water jets.



Don't touch wires, circuit boards, or the device enclosure with wet hands

Don't use the device after it has been exposed to water. Doing so may result in injury or damage to the device and cause it to malfunction. In such cases, contact the producer's technical support.

SAFETY RULES IN CASE OF DAMAGE TO THE ENCLOSURE

During normal operation of the device, the housing is not dangerous. If the case is mechanically damaged, sharp edges and corners may form, posing a potential hazard to the user. In this case, stop using the device and send it to the producer for replacement of the housing.

When operated in accordance with this manual, the device does not pose a danger to person.

RADIATION INFORMATION

When used correctly and following the installation recommendations, the device has no harmful effects on the person body and electrical equipment.

7 STORAGE AND TRANSPORTATION REQUIREMENTS

Vega BS gateways shall be stored in the original packaging in a dry room under conditions that do not allow direct contact with moisture at temperatures +5 °C to +40 °C and relative humidity less than 85 %. The devices must be protected against conductive dust, vapors of acids and alkalis as well as gases that cause corrosion and destroy insulation.

The devices are transported in the original packaging by all transport modes in covered vehicles in accordance with the rules of cargo transportation, operating on this type of transport, and technical conditions of loading and load securing.

During loading and unloading operations and transportation the boxes must not be exposed to sharp impacts and atmospheric precipitation.

The way of stacking the boxes with the product on the transportation vehicle should prevent their movement.

Transportation of the device without packing may result in its breakage.

The gateway transportation is permissible in covered freight compartments of all types at any distance at temperatures -40 °C to +85 °C.

8 CONTENT OF THE PACKAGE

The gateway delivered complete with:

Vega BS gateway – 1 pc.

PoE-injector³ – 1 pc.

Passport – 1 pc.

³ The presence of a PoE injector in the kit depends on the terms of delivery

9 WARRANTY

The manufacturer guarantees that the product complies with the current technical documentation, subject to the storage, transportation and operation conditions specified in the "User Manual".

The warranty period - 36 months from the date of sale, provided that the operating rules, as well as maintenance condition and storage conditions are observed.

In the event of case it is established that the failure of the device has occurred due to reasons beyond the control of the consumer and is related to a defect in materials or violation of technological processes during production, which ultimately makes it impossible to continue using the device, the manufacturer is obliged to provide repair services or replace the defective device or its components within the warranty period.

Technical examination or diagnosis by the producer's staff may be required to determine the cause of failure or nature of damage. Replacement or warranty repair is performed after the producer's confirmation of compliance with the warranty requirements.

The warranty does not apply to PoE-injector.

The manufacturer does not bear warranty obligations in the event of a product failure if:

- ◎ the product does not have the passport;
- ◎ the passport does not have an TCD stamp and / or there is no sticker with information about the device;
- ◎ the serial number (MAC) printed on the product differs from the serial number (MAC) specified in the passport;
- ◎ the product has been subject to alterations in the design which are not provided for in the operational documentation;

- ◎ the product has mechanical, electrical and / or other damage and defects arising from violation of the conditions of transportation, storage and operation;
- ◎ the product has traces of repair outside the manufacturer's service center;
- ◎ the components of the product have internal damage caused by the ingress of foreign objects / liquids and / or natural disasters (flood, fire, etc.);
- ◎ natural wear and tear;
- ◎ storage and operating regulations have been violated;
- ◎ the permissible loads on the device have been exceeded.

The average service life of the product is 5 years.

In the event of a warranty claim, contact the service center:

119A, Bol'shevistskaya Str., Novosibirsk, 630009, Russia.

Tel.: +7 (383) 206-41-35.

e-mail: remont@vega-absolute.ru

| DOCUMENT INFORMATION | |
|----------------------|-----------------------------------|
| Title | Gateway Vega BS |
| Document type | Manual – Translation from Russian |
| Revision and date | 35 of 04 December 2024 |

Revision History

| Revision | Date | Name | Comments |
|----------|------------|------|--|
| 01 | 27.04.2017 | KEV | Document creation date |
| 02 | 15.05.2017 | PKP | Minor edits |
| 03 | 18.05.2017 | KEV | General manual on BS-1 and BS-2 |
| 04 | 13.06.2017 | KEV | Edits in the content of the package |
| 05 | 14.06.2017 | KEV | Part « Configuration » was edit, A5 format |
| 06 | 14.08.2017 | KEV | Antenna mounting recommendation was added |
| 07 | 16.08.2017 | KEV | Part « Operation » was edit |
| 08 | 28.08.2017 | KEV | Minor edits in the « Configuration of a static IP-adress » |
| 09 | 27.09.2017 | KEV | «SIM card installation» was added |
| 10 | 02.11.2017 | KEV | Parts « Gateway setting up for 3G operation », « Recommendations » were added, new format |
| 11 | 29.06.2018 | KEV | Vega BS-1.2 and Vega BS-2.2 description is added, content of the package is changed, working temperatures are changed |
| 12 | 23.08.2018 | KEV | Minor changes |
| 13 | 18.09.2018 | KEV | Minor changes |
| 14 | 24.10.2018 | KEV | Ethernet type added in specification |

| | | | |
|----|------------|-----|--|
| 15 | 20.11.2018 | KEV | Changes in part « Configuration of a static IP-adress », adds to part « Start of work » |
| 16 | 29.04.2019 | KEV | Operating position of DIP-switches changed (fig. 3.3) |
| 17 | 14.11.2019 | KEV | There is a new part added which describes gateway interface |
| 18 | 05.12.2019 | KEV | File links changed on the page 28 and 29 . |
| 19 | 26.03.2020 | KEV | Specification for 3G modem is updated |
| 20 | 06.10.2020 | KEV | Now the setting for 3G operation is only for BS-2.2 |
| 21 | 19.10.2020 | KEV | Power consumption is changed |
| 22 | 28.06.2021 | KEV | Scheduled revision of document |
| 23 | 14.09.2021 | KEV | Note has been added at 15 th page |
| 24 | 29.10.2021 | KMA | Information about the BS-2.2 LTE version has been added, edits in the " SIM-card installation " |
| 25 | 13.01.2022 | KMA | Minor edits |
| 26 | 13.04.2022 | KEV | Scheduled revision, new parts , new board version, changes in part 5 (config file has changed the directory) |
| 27 | 23.08.2022 | KMA | Warranty clarified |
| 28 | 10.11.2022 | KEV | New parts: software updating and maintenance recommendations |
| 29 | 15.12.2022 | KMA | 3G has been removed |
| 30 | 27.04.2023 | KMA | StrongSwan support has been removed |
| 31 | 02.05.2024 | NEE | Minor edits to the "Technical Specifications" section |
| 32 | 27.05.2024 | NEE | Commenting on the Mounting Recommendations |

| | | | |
|----|------------|-----|---|
| 33 | 10.07.2024 | NEE | Edits were made to the section "Operation with the configuration file" on p. 35 |
| 34 | 29.08.2024 | NEE | Changing the body size |
| 35 | 04.12.2024 | NEE | Replacing the minimum power indicator on p. 13 |



vega-absolute.ru

User Manual © Vega-Absolute OOO 2017-2024